



CUSTOMER SUPPORT BULLETIN

Telos Part # 9154 - Zephyr X.21 / V.35 Interface Card Installation Instructions

June 8, 1995

Installation procedure:

1. Power Zephyr off and remove the AC Mains power connector.
2. Remove top cover.
3. On the rear panel, locate and remove the blank panel closest to the RS-232 and parallel port connectors on the Zephyr.
4. Install the X.21 / V.35 card in the position where the blank was removed. Install capture screws.
5. Replace top cover and connect AC Mains power connector.
6. Power the Zephyr on. Go to the second Utility menu and change the setting of the "Network" menu option from "ISDN" to "V.35". You are now ready to use the X.21/V.35 interface
7. To utilize this connection, you will need a data cable from Telos. Cable part # 9812-0000 is used for V.35 while # 9822-0000 is used for X.21. These cables may be purchased from your authorized Telos dealer.

Note: The Zephyr's buttons and dialpad cannot be used to initiate calls when the X.21/V.35 interface is used. All call setup must be handled by the external equipment (such as an ISDN Terminal Adaptor or Switched-56 CSU/DSU). However, the Zephyr's Autodial feature may be used to change modes.

Thank you for your support of Telos Systems. For more information see our web site www.zephyr.com or email support@telos-systems.com, or europe@telos-systems.com.